HG658

Configuring in Layer2 PPPoE for Windows 7

IMPORTANT MESSAGE

Your modem has already been pre-configured, you do not need to follow each step of the set-up guide but should retain this document in case you need to manually configure your equipment.

To configure your PC/Laptop with your wireless password including changing your wireless password, please proceed to step 4.

Contents

- 1. Physical Connection
- 2. Network Configuration
- 3. Configuring Internet
- 4. Configuring Wireless
- 5. IPTV
- 6. Change of Password

1. PHYSICAL CONNECTION

Have your router powered on and connected directly to your PC via Ethernet Cable before you begin, as these instructions are based on wired Ethernet connection


2. NETWORK CONFIGURATION

PPPoE connection does not require you to have an IP address or DNS settings manually encoded on your network card. PPPoE connection uses authentication to establish the Internet connection and once connected your modem will be assigned an IP and DNS settings from TPG.

To begin, your PC needs to receive a private IP address from the router. Most routers have DHCP enabled by default that will take care of this.

To ensure your Network Card is ready for this, please follow the following steps:

- A. Click Start -> Control Panel -> Network and Internet -> Network and Sharing Center -> Change adapter settings
- B. Right click on Local Area Connection and select Properties










C. Click on Internet Protocol Version 4 (TCP/IPv4), and then click Properties



- D. Ensure "Obtain an IP address automatically" is selected
- E. Ensure "**Obtain DNS server address automatically**" is selected F. Click **OK**

eneral	Alternate Configurat	tion			
this cap	i get IP settings assigr ability. Otherwise, yo appropriate IP setting	u need to			
() ()	otain an IP address au	utomatically	d		
	e the following IP add	lress:			
IP ac	ldress:				
Subn	et mask:				
Defa	ult gateway:			<u>.</u>	
O OF	otain DNS server addr	ess autom	atically		
-	e the following DNS se				
Prefe	erred DNS server:				
<u>A</u> lter	nate DNS server:				
V	alidate settings upon e	exit		Adv	anced

3. CONFIGURING ROUTER

- A. Open your browser and in the address bar type http://192.168.1.1 and press Enter
- B. Enter **admin** for both the username and password and click **Login**. If you have changed the login credentials, please enter the current username and password for your router interface.






C. You will see the screen shown on the right. Click **Next**.

	Home Gateway
	Wizard > Wizard Wizard
Status Status	
Basic	Step 1 This wizard helps you to configure the router.
🖏 Advanced	
Xaintenance	Advance Next >

D. Enter your TPG username and password. Click Next.



E. You can change your WiFi details or elect to keep the default settings. The default WiFi SSID is printed on the sticker on the back of your modem. The WiFi password is set to your TPG password by default. Click **Next**.

SSID:	TPG-Y3B8
WPA pre-shared key:	•••••
	Advance < Back Next >
Step 4	
Step 4 Please check the following parameter settings and ensure tha	t the settings are correct. Click Submit for the settings to take eff
Please check the following parameter settings and ensure that	t the settings are correct. Click Submit for the settings to take eff
Please check the following parameter settings and ensure that WAN device:	t the settings are correct. Click Submit for the settings to take eff

.....

WPA pre-shared key:

Please visit http://www.huaweidevice.com for further information for your device.

F. Click **Submit**. Quick Setup complete!

4. CONFIGURING WIRELESS

Things you need to know before you begin:

By default the modem that you purchased from TPG is configured with the following wireless security settings:

SSID (name for the wireless connection): TPG-xxxx (xxxx is a random 4 digit alphanumeric code printed on the sticker underneath your modem)

Authentication Type: WPA-PSK/WPA2-PSK

Encryption: TKIP/AES


Pre Shared Key: initially configured to be the same as your TPG password. You can enter your own text as an option.



Advance < Back Submit

To use Wireless, ensure that you already have set up your wireless adapter.

A. Click Start -> Control Panel -> Network and Internet -> Network and Sharing Center -> Change adapter settings



5. IPTV

Your modem is pre-configured with TPG IPTV settings. Should you require further assistance please contact the TPG Helpdesk on **13 14 23** option **2**.

6. CHANGE OF PASSWORD

For security purposes we highly recommend that you change your password if you are using your default or if you believe your password security has been compromised. For password information, please visit <u>www.tpg.com.au/support</u>.

PLEASE NOTE:

Each time your router is powered on, it will initialize this automated authentication process after which your router will receive a public IP address (fixed or dynamic depending on your plan) and DNS settings from TPG.



